



## WR Methodological Module

### Estimation of carbon stocks of wetland soils (CP-S)

#### I. SCOPE, APPLICABILITY AND PARAMETERS

##### Scope

This module allows for estimation of soil carbon stocks for the baseline and project cases. Uncertainty of estimates is treated in module **X-UNC**. Identification of baseline land-uses is treated in modules **BL-WR**, **BL-WR-WL**, **BL-WR-HM**, and **BL-WR-HM-WL**.

##### Applicability

This module is applicable to wetland soils in the Mississippi Delta. This module is applicable if the soil organic carbon pool is included as part of the project boundary as per applicability criteria in the framework module **WR-MF**. Soil organic carbon shall be included if determined to be significant using module **T-SIG**.

##### Parameters

This module produces the following parameters:

Parameter	SI Unit	Description
$\Delta C_{SOC\_BSL}$	t CO <sub>2</sub> -e	Cumulative total of carbon stock changes of soils for the baseline scenario
$\Delta C_{SOC}$	t CO <sub>2</sub> -e	Cumulative total of the carbon stock changes of soils due to project activities
$SOC_{50cm}$	t CO <sub>2</sub> -e	Amount of carbon in top 50 cm of wetland soil profile; t CO <sub>2</sub> -e ha <sup>-1</sup>

#### II. PROCEDURES

The mean carbon stock in the wetland soils above specific known time horizons will be estimated based on field measurements at fixed locations. Cesium<sup>137</sup> analysis of cores will be used to establish baseline soil carbon stock, while feldspar marker horizons will be used to monitor soil carbon stock through the project lifetime. The number of sampling plots should ensure that they adequately represent the area being measured. The T-PLOTS tool module can be helpful in this regard by providing an estimate of the number of plots needed for monitoring changes in carbon pools at a desired precision level based on the variance of previously collected data.

## Soil Cores

Measurement of the carbon content of wetland soils requires collection of soil cores<sup>1,2,3,4,5</sup>. Any compaction that occurs should be measured and accounted for in the final analysis. An alternative to coring tubes is the use of a McAuley coring device, which allows cores to be taken with virtually no compaction<sup>6</sup>. The number of replicates should be determined by sample variability and desired confidence (e.g., 90%).

## Cesium<sup>137</sup> dating

Soil cores for Cesium-137 isotope analysis should be taken from the project area prior to project activities, or at a suitable reference area, to establish long-term background carbon accumulation rates<sup>7,8,9</sup>. The cores should be sectioned in the field into 2-cm increments and brought to the laboratory, dried at 55°C to a constant weight, weighed for bulk density, ground in a grinding mill, sieved through a 20-mesh screen to achieve a uniform particle size, and analyzed for <sup>137</sup>Cs activity using standard gamma radiation techniques. Slicing must be done with clean steel or plastic tools, samples stored in plastic sacks and kept on ice throughout transport, and then frozen until analysis. Accretion rate is calculated from the height of material above the peak <sup>137</sup>Cs activity, which correlates to circa 1964 when nuclear testing was banned. If a peak cannot be distinguished, the height of material above the start of <sup>137</sup>Cs activity may be used, which correlates to circa 1950, the year of first significant <sup>137</sup>Cs fallout. The carbon fraction of the core samples should also be analyzed using elemental analysis. Soil carbon accumulation rates can then be calculated as a product of average surface accretion rates and average carbon fraction (i.e., equation 2).

---

<sup>1</sup> DeLaune, R.D., Patrick, Jr., W.H., Buresh, R.J., 1978. Sedimentation Rates Determined by <sup>137</sup>Cs. *Nature* 275: 532–533.

<sup>2</sup> Craft, C. B., and W. P. Casey, 2000. Sediment and Nutrient Accumulation in Floodplain and Depressional Freshwater Wetlands of Georgia, USA. *Wetlands* 20: 323–332.

<sup>3</sup> Euliss, et al., 2006. North American Prairie Wetlands are Important Nonforested Land-Based Carbon Storage Sites. *Science of the Total Environment* 361: 179-188.

<sup>4</sup> Gross, M. F., M. A. Hardisky, P. L. Wolf, and V. Klemas. 1991. Relationship Between Aboveground and Belowground Biomass of *Spartina alterniflora* (Smooth Cordgrass). *Estuaries* 14:180–191.

<sup>5</sup> Delaune, R. D., and S. R. Pezeshki, 2003. The role of soil organic carbon in maintaining surface elevation in rapidly subsiding U.S. Gulf of Mexico coastal marshes. *Water, Air, & Soil Pollution* 3: 167-179. 20(1): 57-64.

<sup>6</sup> Bricker-Urso, S., S. W. Nixon, J. K. Cochran, D. J. Hirschberg, and C. Hunt, 1989. Accretion Rates and Sediment Accumulation in Rhode Island Salt Marshes. *Estuaries* 12:300-317.

<sup>7</sup> Ritchie, J.C., and J.R. McHenry, 1990. Application of radioactive fallout cesium-137 for measuring soil erosion and sediment accumulation rates and patterns: a review. *Journal of Environmental Quality* 19: 215-233

<sup>8</sup> DeLaune, R.D., W.H. Patrick, Jr., and R.J. Buresh. 1978. Sedimentation rates determined by <sup>137</sup>Cs dating in a rapidly accreting salt marsh. *Nature* 275: 532-533.

<sup>9</sup> Williams, H.F.L., and W.M. Flanagan. 2009. Contribution of Hurricane Rita storm surge deposition to long-term sedimentation in Louisiana coastal woodlands and marshes. *Journal of Coastal Research* 56: 1671-1675.

## Feldspar Marker Plots

Feldspar markers should be put in place at the start of the project activity. Feldspar marker horizons are prepared by spreading a thin ( $\approx 1\text{cm}$ ) layer of white feldspar clay on the wetland surface<sup>10,11,12,13</sup>. The rate of vertical accretion is calculated by dividing the mean thickness of material above the surface of the horizon by the amount of time the horizon had been in place. Material accumulated above the feldspar marker should be analyzed for carbon content. As with Cesium<sup>137</sup> core analysis, the soil carbon accumulation rates can be calculated as a product of average surface accretion rates and average carbon density.

### A. BASELINE CALCULATIONS

#### Cumulative soil carbon stock changes for the baseline scenario ( $\Delta C_{SOC\_BSL}$ )

The soil carbon stock changes over a given period of time in the baseline scenario ( $\Delta C_{SOC\_BSL}$ ) should be carried out using the following equation:

$$\Delta C_{SOC\_BSL} = f C_{SOC\_BSL} * t \quad (1)$$

where:

$\Delta C_{SOC\_BSL}$	Cumulative soil carbon stock changes for the baseline scenario; t CO <sub>2</sub> -e
$f C_{SOC\_BSL}$	Rate of increase in soil carbon stock for the baseline scenario; t CO <sub>2</sub> -e yr <sup>-1</sup>
$t$	year of monitoring event; years

#### Baseline soil carbon stock rate of change ( $f C_{SOC\_BSL}$ )

The change in carbon stock in the soil pool in the baseline scenario ( $f C_{SOC\_BSL}$ ) will be estimated by determining the carbon accumulated since 1964, or 1950 if peak<sup>137</sup>Cs activity is not evident, and then dividing by the years since that time. The material located above the temporal marker should be analyzed for total carbon and bulk density using standard methods<sup>14</sup>.

---

<sup>10</sup> Cahoon, D. R. and R. E. Turner, 1989. Accretion and Canal Impacts in a Rapidly Subsiding Wetland. Feldspar marker horizon technique. *Estuaries* 12: 260-268.

<sup>11</sup> Conner, W. H., and Day, J. W., 1991. Variations in Vertical Accretion in a Louisiana Swamp. *Journal of Coastal Research*. 7: 617-622

<sup>12</sup> DeLaune, R. D., R. H. Bauman, & J. G. Gosselink, 1983. Relationships among Vertical Accretion, Coastal Submergence and Erosion in a Louisiana Gulf Coast Marsh. *Journal of Sedimentary Petrology* 53: 147-157.

<sup>13</sup> Cahoon, D. R., J. C. Lynch, and R. M. Knaus, 1996. Improved Cryogenic Coring Device for Sampling Wetland Soils. *Journal of Sedimentary Research* 66: 1025-1027.

<sup>14</sup> Brady, N.C., R.R. Weil. 2001. *The Nature and Properties of Soils* (13th Edition). Prentice Hall, Upper Saddle River, NJ.

$$fC_{SOC\_BSL} = \frac{44}{12} \sum_{i=1}^n (CF_{SOC\_BSL\_sample\ i} * BD_{BSLi} * Depth_{BSLi} * Area_{BSLi} * 0.01) / T_{Cs} \quad (2)$$

where:

- $fC_{SOC\_BSL}$  Rate of change in soil carbon stock for the baseline scenario; t CO<sub>2</sub>-e yr<sup>-1</sup>
- 44/12 Ratio of molecular weight of CO<sub>2</sub> to carbon; dimensionless
- $CF_{SOC\_BSL\_sample\ i}$  Carbon fraction of the sample in stratum  $i$  of the baseline scenario, as determined in laboratory; g C g<sup>-1</sup> d.m.
- $BD_{BSLi}$  Bulk density in stratum  $i$  of the baseline scenario as determined in laboratory; g cm<sup>-3</sup>
- $Depth_{BSLi}$  Depth to peak Cesium<sup>137</sup> isotopic marker activity in stratum  $i$  of the baseline scenario; cm
- $Area_{BSLi}$  Area of in stratum  $i$  of the baseline scenario, m<sup>2</sup>
- 0.01 Multiplier to convert grams to tons and cm<sup>2</sup> to m<sup>2</sup>; dimensionless
- $T_{Cs}$  Time between 1964 and the year of sample collection; yr
- $i$  1, 2, 3, ...  $n$  strata in the project scenario

### Baseline Prevented Wetland Loss

The top 50-cm of the wetland soil horizon generally includes the living root zone, which is the most geomorphically unstable, most susceptible to erosion, and has the greatest potential of being decomposed when the vegetation dies and released as CO<sub>2</sub> and CH<sub>4</sub>. Use the equation below to calculate the amount of carbon in the top 50 cm of the wetland soil profile (SOC<sub>50cm</sub>):

$$SOC_{50cm} = \frac{44}{12} \sum_{i=1}^n (CF_{SOC\_BSL\_sample\ i} * BD_{BSLi} * 50 * Area_{BSLi} * 0.01) \quad (3)$$

where:

- $SOC_{50cm}$  Amount of carbon in top 50 cm of wetland soil profile; t CO<sub>2</sub>-e ha<sup>-1</sup>
- 44/12 Ratio of molecular weight of CO<sub>2</sub> to carbon; dimensionless
- $CF_{SOC\_BSL\_sample\ i}$  Carbon fraction of top 50 cm of wetland soil profile in stratum  $i$ , as determined in laboratory; g C g<sup>-1</sup> d.m.
- $BD_i$  Bulk density of top 50 cm of wetland soil profile in stratum  $i$ , as determined in laboratory; g cm<sup>-3</sup>

$Area_i$	Area of stratum $i$ ; $m^2$
$0.01$	Multiplier to convert grams to tons and $cm^2$ to $m^2$ ; dimensionless
$i$	$1, 2, 3, \dots n$ strata in the project scenario

## B. PROJECT CALCULATIONS

### Soil carbon stock generated since the start of project activities ( $C_{SOC}$ )

The carbon stock in the soil pool during project activities ( $C_{SOC}$ ) will be estimated by determining the carbon accumulated above the feldspar marker and then dividing by the years since the marker was put in place (i.e., since the start of project activities). The material located above the feldspar marker should be analyzed for total carbon and bulk density using standard methods<sup>15</sup>.

- Step 1.** Measure the soil organic carbon to the depth of the feldspar marker horizon by using a soil corer.
- Step 2.** Soil samples collected should be aggregated to reduce the variability and analyzed in the laboratory.
- Step 3.** For bulk density analysis, a single core shall be taken next to one for carbon analysis. The samples are then oven dried and weighed for bulk density and soil organic carbon determination.
- Step 4.** The mass of carbon per unit volume is calculated by multiplying the carbon concentration (percent mass) and bulk density ( $g/cm^3$ ).

$$\Delta C_{SOC} = \frac{44}{12} \sum_{i=1}^n (CF_{SOC\_sample\ i,t} * BD_{i,t} * Depth_{i,t} * Area_{i,t} * 0.01) \quad (4)$$

where:

$\Delta C_{SOC}$	Cumulative soil carbon stock changes since start of project activities; t $CO_2$ -e
$44/12$	Ratio of molecular weight of $CO_2$ to carbon; dimensionless
$CF_{SOC\_sample\ i}$	Carbon fraction of the soil above feldspar in stratum $i$ , as determined in laboratory; $g\ C\ g^{-1}\ d.m.$
$BD_i$	Bulk density of the soil above feldspar in stratum $i$ , as determined in laboratory; $g\ cm^{-3}$

<sup>15</sup> Brady, N.C., R.R. Weil. 2001. The Nature and Properties of Soils (13th Edition). Prentice Hall, Upper Saddle River, NJ.

<i>Depth<sub>i</sub></i>	Depth to feldspar marker in stratum <i>i</i> ; cm
<i>Area<sub>i</sub></i>	Area of stratum <i>i</i> ; m <sup>2</sup>
<i>0.01</i>	Multiplier to convert units into ton C
<i>i</i>	1, 2, 3, ... <i>n</i> strata in the project scenario

### C. EX-ANTE ESTIMATION METHODS

The Project Proponent must make an *ex-ante* calculation of all net anthropogenic GHG removals and emissions for all included sinks and sources for the entire crediting period. Project Proponent shall provide estimates of the values of those parameters that are not available before the start of monitoring activities. Project Proponent must retain a conservative approach in making these estimates.

*Ex-ante* net GHG removals by sinks can be estimated using empirical methods or modeling based on peer-reviewed literature or field monitoring, reference sample plots or field monitoring of similar sites, and approved local or national parameters that confirm to the applicability conditions of this methodology in order to assess the verifiable changes in carbon pools. The methodology ensures that the net anthropogenic GHG removals by sinks are estimated under the project in a conservative manner taking into account the uncertainties associated with the secondary data.

This methodology provides for the use of empirical methods as stand alone or as complements to modeling based on peer-reviewed literature for the purpose of *ex-ante* estimation of carbon stock changes. The empirical methods are the methods used in forest/wetland inventory and wetland management studies for estimating biomass, productivity etc. The data from research and published literature that use scientifically accepted empirical methods can be used for *ex-ante* estimation purposes provided such data are based on valid sampling and statistical procedures and are in agreement with the methods, steps and procedures outlined for the estimation of carbon pools under this methodology. For example, species data based on yield tables, peer-reviewed literature, national inventory data or default data, allometric equations, growth models, mortality studies, biomass estimation and nutrient cycling studies and local research such as land records, field surveys, archives, maps or satellite images of the land use/cover before the start of the proposed project activity, field surveys, and expert opinion that confirms to the methods outlined for estimation of carbon stock changes under this methodology can be utilized.

## DATA AND PARAMETERS MONITORED

<b>Data /parameter:</b>	$Area_{BSLi}$
<b>Data unit:</b>	$m^2$
<b>Used in equations:</b>	2 & 3
<b>Description:</b>	Area of stratum $i$ of the baseline scenario
<b>Source of data:</b>	Aerial map (e.g. orthorectified aerial photography or georeferenced remote sensing images)
<b>Measurement procedures (if any):</b>	Monitoring of strata shall be done preferably using a Geographical Information System (GIS), which allows for integrating data from different sources (including GPS coordinates and Remote Sensing data)
<b>Monitoring frequency:</b>	Monitoring must occur for baseline renewal. Where carbon stock enhancement is included, the monitoring frequency can range from 5 to 20 years. In situations where the project adopts a 40-year renewable crediting period, the monitoring frequency can be fixed to coincide with the crediting period.
<b>QA/QC procedures:</b>	
<b>Any comment:</b>	

<b>Data /parameter:</b>	$Area_i$
<b>Data unit:</b>	$m^2$
<b>Used in equations:</b>	4
<b>Description:</b>	Area of stratum $i$
<b>Source of data:</b>	Aerial map (e.g. orthorectified aerial photography or georeferenced remote sensing images)
<b>Measurement procedures (if any):</b>	Monitoring of strata shall be done preferably using a Geographical Information System (GIS), which allows for integrating data from different sources (including GPS coordinates and Remote Sensing data)
<b>Monitoring frequency:</b>	Monitoring must occur for baseline renewal. Where carbon stock enhancement is included, the monitoring frequency can range from 5 to 20 years. In situations where the project adopts a 40-year renewable crediting period, the monitoring frequency can be fixed to coincide with the crediting period.
<b>QA/QC procedures:</b>	
<b>Any comment:</b>	

<b>Data /parameter:</b>	$BD_{BSLi}$
<b>Data unit:</b>	$\text{g cm}^{-3}$
<b>Used in equations:</b>	2 & 3
<b>Description:</b>	Bulk density in stratum $i$ of the baseline scenario as determined in laboratory
<b>Source of data:</b>	Field sampling and laboratory determination.
<b>Measurement procedures (if any):</b>	For bulk density determination, samples (cores) of known volume are collected in the field and oven dried to a constant weight at 105°F (approximately 5d). The total sample is then weighed. The bulk density equals the oven dry weight of the soil core divided by the core volume.
<b>Monitoring frequency:</b>	Monitoring must occur for baseline renewal. Where carbon stock enhancement is included, the monitoring frequency can range from 5 to 20 years. In situations where the project adopts a 40-year renewable crediting period, the monitoring frequency can be fixed to coincide with the crediting period.
<b>QA/QC procedures:</b>	Standard quality control / quality assurance (QA/QC) procedures for forest inventory including field data collection and data management shall be applied. Use or adaptation of QA/QCs already applied in national forest monitoring, or available from published handbooks, or from the IPCC GPG LULUCF 2003, is recommended.
<b>Any comment:</b>	

<b>Data /parameter:</b>	$BD_i$
<b>Data unit:</b>	$\text{g cm}^{-3}$
<b>Used in equations:</b>	4
<b>Description:</b>	Bulk density in stratum $i$ , as determined in laboratory
<b>Source of data:</b>	Field sampling and laboratory determination. The bulk density equals the oven dry weight of the soil core divided by the core volume.
<b>Measurement procedures (if any):</b>	For bulk density determination, samples (cores) of known volume are collected in the field and oven dried to a constant weight at 105°F (approximately 5d). The total sample is then weighed. The bulk density equals the oven dry weight of the soil core divided by the core volume.
<b>Monitoring frequency:</b>	Monitoring must occur for baseline renewal. Where carbon stock enhancement is included, the monitoring frequency can range from 5 to 20 years. In situations where the project adopts a 40-year renewable crediting period, the monitoring frequency can be fixed to coincide with the crediting period.
<b>QA/QC procedures:</b>	Standard quality control / quality assurance (QA/QC) procedures for forest inventory including field data collection and data management shall be applied.

	Use or adaptation of QA/QCs already applied in national forest monitoring, or available from published handbooks, or from the IPCC GPG LULUCF 2003, is recommended.
<b>Any comment:</b>	

<b>Data /parameter:</b>	$CF_{SOC\_BSL\ sample\ i}$
<b>Data unit:</b>	g C g <sup>-1</sup> d.m.
<b>Used in equations:</b>	2 & 3
<b>Description:</b>	Carbon fraction of the sample in stratum <i>i</i> of the baseline scenario, as determined in laboratory
<b>Source of data:</b>	Field sampling and laboratory determination
<b>Measurement procedures (if any):</b>	<p>Soil cores must be taken to capture the full 50 cm soil profile. Compaction should be noted and compensated for in the final calculations. For soil carbon fraction determination, an aggregate sample (e.g., from each core section) is collected, thoroughly dried, ground, and mixed. The prepared sample is analyzed for percent organic carbon using either dry combustion using a controlled-temperature furnace (e.g. LECO CHN- 2000, LECO RC-412 multi-carbon analyzer, or equivalent), dichromate oxidation with heating, or Walkley-Black method.</p> <p>Further guidance is provided in the IPCC 2003 GPG-LULUCF and in Nelson, D.W., and L.E. Sommers. 1982. Total carbon, organic carbon, and organic matter. p. 539–580. In A.L. Page et al. (ed.) Methods of soil Analysis. Part 2. 2nd ed. Agron. Monogr. 9. ASA and SSSA, Madison, WI.</p> <p>Pearson, T., Walker, S. and Brown, S. 2005. Sourcebook for Land Use, Land-Use Change and Forestry Projects. Winrock International and the World Bank Biocarbon Fund. 57pp. Available at:  <a href="http://www.winrock.org/Ecosystems/files/Winrock-BioCarbon_Fund_Sourcebook-compressed.pdf">http://www.winrock.org/Ecosystems/files/Winrock-BioCarbon_Fund_Sourcebook-compressed.pdf</a></p>
<b>Monitoring frequency:</b>	Monitoring must occur for baseline renewal. Where carbon stock enhancement is included, the monitoring frequency can range from 5 to 20 years. In situations where the project adopts a 40-year renewable crediting period, the monitoring frequency can be fixed to coincide with the crediting period.
<b>QA/QC procedures:</b>	Standard quality control / quality assurance (QA/QC) procedures for forest inventory including field data collection and data management shall be applied. Use or adaptation of QA/QCs already applied in national forest monitoring, or available from published handbooks, or from the IPCC GPG LULUCF 2003, is recommended.
<b>Any comment:</b>	

<b>Data /parameter:</b>	$CF_{SOC\_sample,i}$
<b>Data unit:</b>	g C g <sup>-1</sup> d.m.
<b>Used in equations:</b>	4
<b>Description:</b>	Carbon fraction of the sample in stratum <i>i</i> , as determined in laboratory
<b>Source of data:</b>	Field sampling and laboratory determination
<b>Measurement procedures (if any):</b>	<p>The thickness of material accumulated over the feldspar marker horizon needs to be recorded and a subsample removed for C fraction analysis. If the layer is relatively thin (i.e., &lt;10 cm), removal with a blade or shovel may be appropriate in some cases. Soil cores are necessary for thicker layers. Compaction should be noted and compensated for in the final calculations. For soil carbon determination, an aggregate sample (e.g., every 2 cm along the core) is collected, thoroughly dried, ground, and mixed. The prepared sample is analyzed for percent organic carbon using either dry combustion using a controlled-temperature furnace (e.g. LECO CHN- 2000, LECO RC-412 multi-carbon analyzer, or equivalent), dichromate oxidation with heating, or Walkley-Black method.</p> <p>Further guidance is provided in the IPCC 2003 GPG-LULUCF and in Nelson, D.W., and L.E. Sommers. 1982. Total carbon, organic carbon, and organic matter. p. 539–580. In A.L. Page et al. (ed.) Methods of soil Analysis. Part 2. 2nd ed. Agron. Monogr. 9. ASA and SSSA, Madison, WI.</p> <p>Pearson, T., Walker, S. and Brown, S. 2005. Sourcebook for Land Use, Land-Use Change and Forestry Projects. Winrock International and the World Bank Biocarbon Fund. 57pp. Available at:  <a href="http://www.winrock.org/Ecosystems/files/Winrock-BioCarbon_Fund_Sourcebook-compressed.pdf">http://www.winrock.org/Ecosystems/files/Winrock-BioCarbon_Fund_Sourcebook-compressed.pdf</a></p>
<b>Monitoring frequency:</b>	Monitoring must occur for baseline renewal. Where carbon stock enhancement is included, the monitoring frequency can range from 5 to 20 years. In situations where the project adopts a 40-year renewable crediting period, the monitoring frequency can be fixed to coincide with the crediting period.
<b>QA/QC procedures:</b>	Standard quality control / quality assurance (QA/QC) procedures for forest inventory including field data collection and data management shall be applied. Use or adaptation of QA/QCs already applied in national forest monitoring, or available from published handbooks, or from the IPCC GPG LULUCF 2003, is recommended.
<b>Any comment:</b>	

<b>Data /parameter:</b>	$Depth_{BSLi}$
<b>Data unit:</b>	cm
<b>Used in equations:</b>	2
<b>Description:</b>	Depth to peak $^{137}\text{Cs}$ isotopic marker activity in stratum $i$ of the baseline scenario
<b>Source of data:</b>	Field sampling and laboratory determination
<b>Measurement procedures (if any):</b>	Soil cores for $^{137}\text{Cs}$ analysis should be sectioned in the field into 2-cm increments, separated in labeled bags, and brought to the laboratory to be analyzed for $^{137}\text{Cs}$ activity. The increment with peak $^{137}\text{Cs}$ activity correlates to circa 1963 when nuclear testing was banned. If a peak cannot be distinguished, the increment when $^{137}\text{Cs}$ activity starts may be used, which correlates to circa 1950, the year of first significant $^{137}\text{Cs}$ fallout.
<b>Monitoring frequency:</b>	Once for each $^{137}\text{Cs}$ core collected for <i>ex-ante</i> estimation of the baseline
<b>QA/QC procedures:</b>	Cesium-137 analysis must be carried out by an accredited laboratory with previous isotopic analysis experience.
<b>Any comment:</b>	The rate of vertical accretion is calculated by dividing the mean thickness of material above the $^{137}\text{Cs}$ marker by the amount of time since 1963 or 1950, depending on if peak $^{137}\text{Cs}$ activity can be identified (see above for details).

<b>Data /parameter:</b>	$Depth_i$
<b>Data unit:</b>	cm
<b>Used in equations:</b>	4
<b>Description:</b>	Depth to feldspar marker in stratum $i$ ;
<b>Source of data:</b>	Recorded in the field at feldspar plots.
<b>Measurement procedures (if any):</b>	This should be done <i>in situ</i> by cryogenic coring or by measuring the depth to the feldspar layer with a hand ruler when cores are taken for bulk density and %carbon.
<b>Monitoring frequency:</b>	Monitoring must occur for baseline renewal. Where carbon stock enhancement is included, the monitoring frequency can range from 5 to 20 years. In situations where the project adopts a 40-year renewable crediting period, the monitoring frequency can be fixed to coincide with the crediting period.
<b>QA/QC procedures:</b>	Soda feldspar should be chosen that does not float on water, but rather sinks and consolidates.
<b>Any comment:</b>	The rate of vertical accretion is calculated by dividing the mean thickness of

	material above the surface of the horizon by the amount of time the horizon had been in place.
--	--

<b>Data /parameter:</b>	$T_{Cs}$
<b>Data unit:</b>	yr
<b>Used in equations:</b>	2
<b>Description:</b>	Time since 1963 or 1950 (see discussion above for details) and the year of sample collection
<b>Source of data:</b>	Time elapsed from 1963 (the year when nuclear testing was banned) or 1950 (the year of first significant $^{137}\text{Cs}$ fallout), to the year of sample collection. See discussion above for details.
<b>Measurement procedures (if any):</b>	
<b>Monitoring frequency:</b>	Once for each Cesium $^{137}$ core collected
<b>QA/QC procedures:</b>	Cesium-137 analysis must be carried out by an accredited laboratory with previous isotopic analysis experience
<b>Any comment:</b>	